





DIAGNOSTIC SOIL ANALYSIS PRODUCTS

<p>1. Mascaro Profile Sampler 7 Inch Deep Order #: MPS1-S</p> <p style="text-align: right;">Price: 210.00</p>	
	<p>With the new and improved Mascaro Profile Sampler, the sample is extracted and the cutter blade is simply opened with the aid of a specially designed hinge.</p> <p>This device takes an undisturbed soil profile 7 inches deep, 3 inches wide and 1/2 inch thick, which can be viewed instantly. Sample can be photographed and easily replaced without damaging the putting surface. Overall length is 25 inches long.</p>
<p>2. Heavy Duty Mascaro Profile Sampler 7 Inch Deep Order #: MPS2-S</p> <p style="text-align: right;">Price: \$ 225.00</p>	
	<p>The New Heavy Duty Mascaro Profile Sampler extracts a cross section of the soil profile with this 7" deep, 3" wide and 1/2" thick sampler. This Heavy-duty sampler has a 30-inch long handle and the reinforced cutter blades allow reliable use even in hard or rocky soils.</p> <p>The cutter blade opens with the aid of a specially designed hinge exposing the Soil Profile with unmatched quality. Overall Height is 38 inches long.</p>
<p>3. Mascaro Profile Sampler 12 inch Deep Order #: SPS3-S</p> <p style="text-align: right;">Price: 275.00</p>	
	<p>Clearly inspect the soil profile with this 12 inch deep, 3 inch wide and 1/2 inch thick sampler. The sample is extracted and the cutter blade is simply opened with the aid of a specially designed hinge.</p> <p>Now you can inspect sand based athletic fields down to the drainage layer. This extra deep soil profile sampler also useful in examining the entire soil profile at one time, without disturbing the surface.</p>

<p>4. Short Mascaro Profile Sampler (Short Handle) 7 Inch Deep Order #: MPS1-S</p> <p style="text-align: right;">Price: \$ 210.00</p>	
	<p>This is the same as the MPS1-S Mascaro Profile Sampler but with a short handle welded onto the cutter blade. The sample is extracted and the cutter blade is simply opened with the aid of a specially designed hinge. Overall length is 19.5 inches long.</p> <p>This soil sampler takes an undisturbed soil profile 7 inches deep, 3 inches wide and 1/2 inch thick, which can be viewed instantly. The short model is ideal for placing inside a briefcase or suitcase for traveling.</p>
<p>5. Pocket Mascaro Profile Sampler 7 Inch Deep Order #: PMPS1-S</p> <p style="text-align: right;">Price: \$ 225.00</p>	
	<p>Now, you can have a high quality Soil Profile Sampler with you wherever you go with the new Pocket Mascaro Profile Sampler,</p> <p>This unique tool takes a full seven-inch deep, three inch wide and one half-inch thick profile, yet it folds up into the same compact dimensions for carrying from place to place.</p>
<p>6. Handle Extension for Pocket Mascaro Profile Sampler Order #: PMPS2-S</p> <p style="text-align: right;">Price (Handle Only): \$ 50.00</p>	
	<p>This handle attachment simply screws onto the new Pocket Mascaro Profile Sampler to allow the tool to become the same size as the 27 inch unit. However the handle can be removed whenever you are in need of the compact unit for travel.</p> <p>*Price is for handle only</p>
<p>7. Soil Profile Sampler 7 Inch Deep Order #: SPS2-S</p> <p style="text-align: right;">Price: \$ 220.00</p>	
	<p>The original Soil Profile Sampler since 1945! The Soil Profile Sampler extracts a cross section of soil with this 7 inch deep, 3 inch wide and 1/2 inch thick sampler. The handle unscrews and the cutter blades separate to expose the soil profile.</p> <p>Samples can be viewed and then placed back into the athletic field or grass infield with no disturbance to the surface.</p>