





24. Turf-Tec Infiltration Rings - 6 and 12 inch Order #: IN5-W Price: \$ 200.00	
	The Turf-Tec Infiltration Rings allow for field infiltration rates to be measured in sand based soils. This tool is ideal for turfgrass students. It has a 6-inch inner ring and a 12-inch outer ring. A welded gripped handle is attached to galvanized rings to allow easy insertion into the soil and to insure proper centering of the rings. These rings are constructed out of 20 Gauge galvanized steel.
26. Turf-Tec Heavy Duty Tall Infiltration Rings Order #: IN8-W Price: \$ 325.00 (With port for IN12 Mariotte Tubes) Order #: IN8P-W Price: \$ 375.00	
	The new Turf-Tec Heavy Duty Tall Infiltration Rings allow the field infiltration rates to be measured. This tool conforms to the new 2006 Pennsylvania Stormwater Best Management Practices Manual. The Turf-Tec Heavy Duty Tall Infiltration Rings have a 6 inch inner ring and a 12 inch outer ring with a 7 inch height. A gripped rubber handle is welded across the rings to keep them concentric and allow easy insertion into, and removal from the soil. These rings are ideal for hard soil types.
27. Turf-Tec Driving Plates for Turf-Tec 6 and 12 inch Infiltration Rings Order #: IN6-W Price: \$ 99.00	
	The new driving plate for the Turf-Tec 6 and 12 inch Infiltration Rings allow the infiltration rings to be hammered into the ground for ease of insertion. The specially designed plate fits directly overtop the center handle assembly on the IN5-W, IN7-W and IN8-W model Infiltration Rings.
	36. Evapotranspiration (ET) Gauge Order #: ETG1-W Price: \$ 400.00 This Evapotranspiration gauge easily shows the amount of water needed for irrigation by reading the sight glass. All you add is distilled water. Daily readings can be taken to save water. The top of the unit is constructed from a ceramic plate that is covered with a green cloth fabric to emulate the turfgrass canopy. As water evaporates off the top of the ET Gauge, the sight glass on the side indicates the Evapotranspiration level. Irrigation can be applied based upon actual simulated turfgrass usage. The unit comes with mounting bracket and full instruction manual on calculating ET rates.

	33. Turf-Tec Moisture Sensor Order #: MS1-W Price: \$ 340.00 The Turf-Tec Moisture Sensor is one of the most necessary tools on an athletic field. The Moisture Sensor is calibrated in percentages and read outs are immediate. Check moisture at any level from 1 inch to 4 inches deep. Quick adjustable base allows easy depth adjustment for readings above the root zone, in the root zone and below the root zone. Unit will also identify dry spots before they become visually apparent without causing damage to stressed turfgrass. Water movement problems like layers are easily detected with variable depth feature. Readings are in percentages from 0% to 100%. By testing soil moisture before tournaments, you will insure each athletic field will play the same way and require the same cleat depth.	
	Moisture Sensor Replacement Parts	
	34. Turf-Tec Moisture Sensor Replacement Probe Order #: TTMP75-W Price: \$ 75.00	
	35. Turf-Tec Moisture Sensor replacement Spike 4" Set 2 Order #: TTMP26-W Price: \$ 25.00	
33C. Field Scout Digital Moisture Sensor Order #: MSFS1-W Price: \$ 999.00		
	The Field Scout Digital Moisture Sensor allows you to monitor and record soil moisture quickly and accurately with TDR technology (time-domain measurement technology). The Field Scout Digital Moisture Sensor offers turfgrass managers a portable unit to accurately measure soil moisture across the full range of soil moisture conditions. Unit comes standard with one set of probes listed below (Select one size). The Unit has two volumetric water content modes; one for standard soils and one for higher clay soils. In volumetric water content (VWC) mode, the meter converts a measured electrical signal into percent soil moisture content. Unit includes software and PC cable. Mapping software requires GPS Unit; not included. MSFS1-Cable - Field Scout GPS Cable \$39.00 MSFSP01 Replacement Spikes 1.5 inch (3.8cm) \$56.00 MSFSP03 Replacement Spikes 3 inch (7.5cm) \$56.00 MSFSP04 Replacement Spikes 4.8 inch (12 cm) \$56.00 MSFS1-USB-Cable - Serial to USB Cable \$32.00 MSFS1-GPS-Bracket - Mounting Bracket (GPS) \$124.00	