

	<p>60. Macroscope 45X Power with hard case Order #: MACR451-L Price: \$ 220.00</p> <p>Identical to Macroscope 25X unit but with 45-power magnification. The 45 Power Macroscope allows you to look closely at disease symptoms like leaf lesions and disease mycelium. Roots can also be examined to see if nematodes are damaging roots. Unit also includes hard protective case.</p>
	<p>61. Macroscope 18 - 36X Zoom with hard case Order #: MACR18-36-L Price: \$ 320.00</p> <p>Macroscope 18-13 is a zoom unit that will allow you to view objects with varying magnification powers that range from 18X power up to 36X power.</p> <p>The unit incorporates a measuring scale that provides measurements in inches or millimeters that is valid at either maximum or minimum magnification. Unit includes hard protective case.</p>
<p>Macroscope Accessories</p>	
	<p>62. Macroscope Computer Camera Attachment. Order #: MACRCCA-L Price: \$ 240.00</p> <p>The new Macroscope computer camera attachment is specifically designed to attach directly onto the top of the Macroscope 25X or 45X models. This new attachment for the Macroscope allows direct imaging of objects from the Macroscope to your computer.</p> <p>The new computer camera attachment plugs into your USB port on any desktop or laptop computer and easy to use software allows you to see live real time images and then capture the still images you see on your computer screen. Software included.</p>
	<p>63. Macro-Light pen Light attachment Order #: MACRLP-L Price: \$ 65.00</p> <p>Slip over pen light attachment allows light to shine onto subject matter viewed by Macroscope.</p>
	<p>64. Macroscope Camera Attachment Order #: MACRCA-52-L Price: \$ 40.00</p> <p>Macro-Photo adapts a Macroscope unit so it fits a 52 mm camera lens.</p>

<p>64A Turf-Tec IPM Scope (640x480 Pixel) 64B IPM Scope Video Upgrade* 64C Turf-Tec IPM Scope High Resolution (1280 X 1024 Pixel)</p>	<p>Order # IPM1-L Price: \$ 360.00 Order # IPM-VID-L Price: \$ 50.00 Order # IPM2-L Price: \$ 810.00</p>
 	<p>The Turf-Tec IPM Scope combines advanced digital optics and LED lighting in a computerized microscope that fits in the palm of your hand. 40 - 140X magnification lets you zoom in on the fine details of insects and plant disease symptoms.</p> <p>Place the Turf-Tec IPM Scope over the sample, and comfortably view the image right on your computer screen, instead of straining to look into a tiny eyepiece. Capture images, easily add labels, and take measurements and even draw right on the live image.</p> <p>The Turf-Tec IPM Scope comes with all the software required to capture and archive your still images. <u>The video upgrade bundle and high resolution units can be purchased separately.</u></p>
	<p>65. Turf-Tec Height of Cut Gauge Order # HG1-G Price: \$ 100.00</p> <p>The Turf-Tec Height of Cut Gauge is specially designed to test the actual cutting height of grass on any finely manicured turfgrass area. It accurately allows you to compare height of cut with mower setting right on the turfgrass area. The Gauge is calibrated to measure in 1/32 of an inch increment (and thousands of an inch) from 1/32 (.03125) to 1 inch. Simply set the height of cut gauge to the desired depth, lock it into place and place on the turfgrass surface. If grass blade tips are directly below the cut out on the base, the height of cut is correct.</p>
<p>65A. Turf-Tec Height of Cut Prism Gauge. Order # HGPRISM-G</p>	<p>Price: \$ 300.00</p>
 	
<p>The Grass Height Prism Gauge is made from solid glass and is designed to tell you the actual height of cut that the mower is making on the turfgrass area as well as the quality of cut and smoothness of the surface. Grass Height Prism Gauge includes solid glass prism in stainless steel frame. Graduated lines are inscribed at 1/16th inch, 1/10th, 1/100th of an inch and 1 mm intervals and measures grass up to 1 5/8 inches or 40 millimeters tall. Unit comes in hard plastic protective case. Check the actual cutting height and quality of cut on your infields.</p>	